









Alarms

	Causes	Reasons	Solutions
	The water flow sensors work without pressing the filter or heat button.	1. The water flow sensor flags didn't fall back into the correct position. 2. The water flow sensors are broken.	1. Unplug the plug gently, strike the side of the pump but not violently, and plug it back in. 2. To get assistance visit our website www.bestwaycorp.com support section.
	After starting or during the functions of filtering or/and heating, the water flow sensors do not detect water flow.	1. You forgot to remove the 2 stopper caps from inside the pool. 2. Filter cartridges are dirty. 3. Activate the filter or heat system and put your hand in front of the outlet pipe inside the pool to check if you can feel water flowing out. a. If no water flows out the water pump is broken. b. Water flows out but the alarm  appears, the water flow sensors are broken.	1. Remove the 2 stopper caps before heating, refer to Assembly section in the User's Manual. 2. Remove the filter set from inside the pool and push the filter or heat button. If no alarm appears, clean or change the filter cartridges install the filter set inside the pool. 3. To get assistance visit our website www.bestwaycorp.com support section.
	The pump's thermometer reads the water temperature below 4°C (40°F).	1. The water temperature is lower than 4°C (40°F) 2. If the water temperature is higher than 7°C (44.6°F), the pump's thermometer is broken.	1. The spa is not designed to operate with water temperatures lower than 4°C (40°F). Unplug the pump and only re-start the pump when the water temperature reaches 6°C (43°F). 2. To get assistance visit our website www.bestwaycorp.com support section.
	The pump's thermometer reads the water temperature over 50°C (122°F).	1. The water temperature is over 50°C (122°F) 2. If the water temperature is lower than 45°C (113°F), the pump's thermometer is broken.	1. The spa is not designed to operate with water temperatures greater than 40°C (104°F). Unplug the pump and only re-start the pump when the water temperature reaches 38°C (100°F) or lower. IMPORTANT: Before you re-start the pump, push the pump's reset button. 2. To get assistance visit our website www.bestwaycorp.com support section.
	The pump's thermometer connections have issues.	1. The pump's thermometer connectors don't work properly. 2. The pump's thermometer is broken.	To get assistance visit our website www.bestwaycorp.com support section.
	The manual reset thermal cut-out has problem.	The manual reset thermal cut-out trips off.	1. Unplug the pump and push the reset button, then plug the pump back in. 2. In case the alarm still remains, check the RESET BUTTON section in manual. 3. To get assistance visit our website www.bestwaycorp.com support section.
	Ground Connection Failed.	1. The ground bonding of your home has some problem. 2. The pump has some problem.	To get assistance visit our website www.bestwaycorp.com support section.

MAINTENANCE

NOTE: Your spa will require additional air to be added from time to time. Changes in temperature from day to night will change the pressure in the spa and may cause a certain amount of deflation. Please follow the Assembly instructions and drain the spa before inflating to the accurate pressure needed.


CAUTION: YOU MUST ENSURE THE PUMP IS UNPLUGGED BEFORE BEGINNING SPA MAINTENANCE TO AVOID RISK OF INJURY OR DEATH.

Filter Cartridge Maintenance

NOTE: To ensure your spa water stays clean, check and clean your filter cartridges every day follow the steps below.



P04674
Filter Set



58323
Filter Cartridge



NOTE: We recommend changing your filter cartridges every week or, if the filter cartridges remain soiled and discolored, they should be replaced.

Cover Maintenance

The cover shall be cleaned inside and out periodically using a suitable solution that includes adequate disinfection (e.g. 10 mg/l of Free Chlorine).

Water Maintenance

Many pollutants in the water settle on surfaces below the water line. These pollutants can cause bacterial, algal or fungal growth. It is recommended that spas are cleaned as regularly as necessary. After a time, tenacious stains or biofilms may develop on the accessible surfaces below the water line or high concentrations of salts or unwanted reaction by-products may also occur. Depending on hygienic condition, cleanliness, visibility, odour, debris and stains, it is recommended to change the water completely and clean/disinfect the spa. When emptying the spa, the regulations and the instructions for draining the water shall be observed.

Keeping your SPA water clean and chemically balanced is necessary. Simply cleaning the filter cartridge is not enough for proper maintenance, we recommend you use pool chemicals to maintain water chemistry and chlorine or bromine tablets (do not use granules) with the chemical dispenser. Water quality will be directly related to frequency of use, number of users and overall maintenance of the spa. The water should be changed every 3 days if there is no chemical treatment being performed with the water.

It is highly recommended to use tap water for spa filling to minimize the influence of unwanted content, such as minerals. Barefoot areas and relaxing areas shall be cleaned as well. No cleaning water may flow into the spa or spa water cycle. The dirt and cleaning agents shall be rinsed carefully to drain in the spa surround.

Note: We recommend you take a shower before using your Lay-Z-Spa, as cosmetic products, lotions, and other residues on the skin can quickly degrade water quality. To use the chemical dispenser, please follow the below instruction.

Using chemical tablets (not included):

